

Ksoloti Core v0.7 and later

PWM* Pins PA5 & PA15 cannot both be used for PWM simultaneously.
PWM Pins PA6 & PB4 cannot both be used for PWM simultaneously.

MRX* UART pin for MIDI input. Can receive direct MIDI signals from another MCU or external MIDI signals via an optocoupler. Cannot be used as input simultaneously with the MI4, MI5 (DIN MIDI) pins.

